

## **Timing the Rear Axle Bird Cages**

1. After using the Rear Axle Assembly Sheet to space your rear axle correctly (make sure axle nuts are done up tight), insert the axle in the car on 3.25" set up blocks 2. Fasten the rear radius rods, brake control rod, and Jacob's ladder to the axle

3. Without torsion stops installed, fasten the rear torsion arms to the rear birdcage pick ups.

4. To time the rear birdcages, use an angle finder on the front portion of the bird cage that is flat (as shown)

5. Find 90° by adjusting the length of the rear radius rods (refrain from using Phone Apps as angle finders)

Notes

