




Switch Panel Diagram



- (-) Grounds to Engine (back of block)
- Battery Ground (or chassis)
 - ECU/Wiring Ground
 - Fuel Pump Ground
 - Power Steering Ground

Notes

DRIVEN