

GEN 4 600 NUT & BOLT LIST

Assembly checklist - Page 1 of 4

Category	Qty	Type	Size	Description / Location	Checked
Front End	4	Bolt-G8-HH	3/8-24 x 1.25	Radius Rod to Chassis	☐
Front End	2	Bolt-G8-HH	3/8-24 x .75	Shock to Chassis	☐
Front End	1	Bolt-G8-HH	3/8-24 x 2.00	Drag Link to Steering Rack	☐
Front End	1	Bolt-G8-HH	3/8-24 x 3.25	LF Steering Arm, DL, TR	☐
Front End	1	Bolt-G8-HH	3/8-24 x 2.25	RF Steering Arm, TR	☐
Front End	4	Bolt-SH	3/8-16 x 1.50 Socket Head	LF/RF Steering Arm to Spindle	☐
Front End	3	Nut-Nylock/Half	3/8-24 Half Nut	Radius Rod to Front Axle	☐
Front End	1	Nut-Nylock	3/8-24 Full Nut	Pan Hard to Front Axle	☐
Front End	2	Nut-Nylock	3/8-24 Full Nut	LF/RF Steering Arm, DL, TR	☐
Front End	1	Nut-Stover	3/8-24 Stover Nut	Drag Link to Steering Rack	☐
Front End	1	Washer-AN	3/8 AN Washer	RF Steering Arm, TR	☐
Front End	4	Washer-AN	3/8 AN Washer	LF/RF Steering Arm to Spindle	☐
LF Brake	2	Bolt-CS	3/8-16 x 1.50 Countersunk	LF Steering Arm to Spindle	☐
LF Brake	5	Bolt-BH	Button Head	LF Brake Rotor to Keizer Hub	☐
LF Brake	2	Bolt-G8-HH	5/16-24 x 1.00	Joes Caliper to Caliper Mounting Bracket	☐
LF Brake	2	Bolt-G8-HH	1/4-28 x 1.50	Proportioning Valve to Chassis Bracket	☐
LF Brake	4	Washer-AN	1/4 AN Washer	Proportioning Valve to Chassis Bracket	☐
LF Brake	2	Nut-Nylock	1/4-28 Full Nut	Proportioning Valve to Chassis Bracket	☐
Steering	2	Bolt-G8	5/16-20 x 2.50	Steering Rack to Chassis	☐
Steering	2	Bolt-G8	5/16-24 x 2.00	Steering Drop Bracket to Chassis	☐
Steering	2	Nut-Nylock	5/16-24 Full Nut	Steering Rack to Chassis	☐
Steering	2	Nut-Nylock	5/16-24 Full Nut	Steering Drop Bracket to Chassis	☐
Steering	4	Washer-AN	5/16 AN Washer	Steering Rack to Chassis	☐
Steering	4	Washer-AN	5/16 AN Washer	Steering Drop Bracket to Chassis	☐

GEN 4 600 NUT & BOLT LIST

Assembly checklist - Page 2 of 4

Category	Qty	Type	Size	Description / Location	Checked
Rear End	1	Bolt-G8-HH	7/16-20 x 1.25	RR Radius Rod to Chassis	☐
Rear End	1	Bolt-G8-HH	7/16-20 x 3.50	LR Radius Rod to Chassis / Brake Rod	☐
Rear End	1	Nut-Nylock/Full	7/16-20 Full Nut	LR Radius Rod to Chassis / Brake Rod	☐
Rear End	3	Bolt-G8-HH	3/8-24 x 1.25	Radius Rod to Birdcage	☐
Rear End	2	Bolt-G8	7/16-24 x 2.25 (Big Shoulder)	Torsion Arm to Birdcage (Custom)	☐
Rear End	2	Bolt-Socket Head	10/32 Socket Head	Safety for Birdcage Bolt	☐
Rear End	2	Bolt-G8	3/8-24 x 3/4	Shock to Chassis	☐
Rear End	6	Bolt-G8-HH	1/4-28 x .750	Brake Rotor to Brake Hub	☐
Rear End	6	Washer-AN / Thin	1/4 AN Washer / Thin	Brake Rotor to Brake Hub	☐
Rear End	8	Washer-AN / Thin	3/8 AN Washer - Thin	Jacobs Ladder Assembly	☐
Rear End	1	Quick Pin	3/8 x 1.25 Pin	Jacobs Ladder to RR Birdcage	☐
Rear End	1	Rue Clip	Rue Clip	Jacobs Ladder to RR Birdcage	☐
Rear End	2	Bolt-SH	3/8-24 x 1.25 Socket Head	Brake Caliper Bracket to Brake Carrier	☐
Rear End	2	Washer-AN	3/8 AN Washer	Brake Caliper Bracket to Brake Carrier	☐
Rear End	2	Nut-Stover	3/8-24 Stover Nut	Brake Caliper Bracket to Brake Carrier	☐
Rear End	6	Bolt-G8-HH	1/4-28 x .750	Brake Rotor to Brake Hub	☐
Rear End	6	Washer-AN / Thin	1/4 AN Washer / Thin	Brake Rotor to Brake Hub	☐
Rear End	2	Bolt-CS	5/16-18 x 1.00 Countersunk	Chain Guide Plate to LR Birdcage	☐
Rear End	4	Bolt-CS	1/4-28 x 2.50 Countersunk	Chain Guide Block to Chain Guide Plate	☐
Bumpers	14	Bolt-Socket Head	10/32 x 1.25 Socket Head	Nerf Bar Bolt	☐
Bumpers	14	Nut-Nylock	10/32 Nut	Nerf Bar Nut	☐

GEN 4 600 NUT & BOLT LIST

Assembly checklist - Page 3 of 4

Category	Qty	Type	Size	Description / Location	Checked
Wing	2	Bolt-G8-HH	5/16-24 x 1.50	T-Post Pinch to Chassis	☐
Wing	4	Washer-AN	5/16 AN Washer	T-Post Pinch to Chassis	☐
Wing	2	Nut-Nylock/Full	5/16-24 Nylock / Full Nut	T-Post Pinch to Chassis	☐
Wing	2	Bolt-G8-HH	5/16-24 x 1.00	Rear Wing Tree to Chassis	☐
Wing	2	Nut-Nylock/Half	5/16-24 Nylock / Half Nut	Rear Wing Tree to Chassis	☐
Wing	2	Bolt-G8-HH	5/16-24 x 1.25	Manual Wing Slider to Chassis	☐
Wing	4	Washer-AN	5/16 AN Washer	Manual Wing Slider to Chassis	☐
Wing	2	Nut-Nylock/Half	5/16-24 Nylock / Half Nut	Manual Wing Slider to Chassis	☐
Wing	1	Bolt-G8	5/16-24 x 1.00	Manual Wing Slider to Wing Tree	☐
Wing	2	Bolt-G8	5/16-24 x 1.25	Rear Wing Tree to Wing	☐
Wing	4	Washer-AN	5/16 AN Washer	Rear Wing Tree to Wing	☐
Wing	2	Nut-Nylock/Half	5/16-24 Nylock Half Nut	Rear Wing Tree to Wing	☐
Wing	4	Bolt-G8-HH	1/4-28 x 1.00	Nose Wing to Posts / Straps	☐
Wing	4	Nut-Nylock/Half	1/4-28 Nylock Half Nut	Nose Wing to Posts / Straps	☐
Wing	2	Bolt-G8-HH	5/16-24 x 2.00	Electric Wing Slider to Chassis / Wing Tree	☐
Wing	2	Nut-Nylock/Full	5/16-24 Nylock Full Nut	Electric Wing Slider to Chassis / Wing Tree	☐

GEN 4 600 NUT & BOLT LIST

Assembly checklist - Page 4 of 4

Category	Qty	Type	Size	Description / Location	Checked
Misc	4	Bolt-SH	5/16-18 x .500 Socket Head	Tank to Chassis	☐
Misc	8	Washer-AN	1/4 AN Washer	Tank to Chassis	☐
Misc	4	Bolt-G8	1/4-28 x .750	Battery Box to Floor	☐
Misc	4	Nut-Nylock/Half	1/4-28 Nylock / Half Nut	Battery Box to Floor	☐
Misc	8	Washer-AN	1/4 AN Washer	Battery Box to Floor	☐
Misc	4	Bolt-G8-HH	5/16-24 x 1.00	Radiator Mounting Bracket to Chassis	☐
Misc	4	Washer-AN	5/16 YZ Washer	Radiator Mounting Bracket to Chassis	☐
Misc	4	Nut-Nylock/Half	5/16-24 Nylock / Half Nut	Radiator Mounting Bracket to Chassis	☐
Misc	4	Rubber Grommet	5/16 ID 9/16 OD	Radiator Mounting Bracket to Chassis	☐
Misc	4	Bolt-G8-HH	1/4-20 x .500	Radiator Mounting Bracket to Radiator	☐
Misc	4	Washer-Lock	1/4 Lock Washer	Radiator Mounting Bracket to Radiator	☐
Misc	1	Quick Pin	3/8 x 1.00 Quick Pin	Shifter Handle to Chassis	☐
Misc	1	Rue Clip	Rue Clip	Shifter Handle to Chassis	☐
Misc	1	Bolt-G8-HH	1/4-28 x 1.75	Shifter Cable to Shifter Handle	☐
Pedals	2	Bolt-G8-HH	3/8-24 x 1.75	Pedal to Pedal Bar	☐
Pedals	2	Nut-Nylock	3/8-24 Nylock / Full Nut	Pedal to Pedal Bar	☐